tehnoteka

https://tehnoteka.rs

Uputstvo za upotrebu (EN)

ENERGY SISTEM slušalice BT Travel 6 ANC

ENERGY SISTEM

Tehnoteka je online destinacija za upoređivanje cena i karakteristika bele tehnike, potrošačke elektronike i IT uređaja kod trgovinskih lanaca i internet prodavnica u Srbiji. Naša stranica vam omogućava da istražite najnovije informacije, detaljne karakteristike i konkurentne cene proizvoda.

Posetite nas i uživajte u ekskluzivnom iskustvu pametne kupovine klikom na link:

https://tehnoteka.rs/p/energy-sistem-slusalice-bt-travel-6-anc-akcija-cena/

ENGLISH

Introduction 3
Care and maintenance 3
Technical specifications 4
Audio 4
Active Noise Cancelling (ANC) 4
Connectivity 4
Hands-free microphone 4
Cable 4
Battery 4
Other features 4
Product content 4
Buttons and ports 5
Switching on and off the device 5
Bluetooth® pairing 6
Bluetooth playback control 6
Call control 6
Using the Voice Assistant feature 6
ANC (Active Noise Cancelling) 6
Audio input 7
Battery life 7
Charging the battery 7
Reset 8
Warranty 8
Trademarks 8
Declaration of conformity 8

Introduction

- Thank you for trusting our company and buying the new *Headphones BT Travel 6 ANC*. We hope you enjoy the product.
- We recommend reading this manual to make the most of the device and enjoy maximum performance.

Care and maintenance

- Do not expose your *Headphones BT Travel 6 ANC* to impacts, dust, humidity or high temperatures.
- Do not use neither corrosive nor abrasive cleaning products.
- Keep the headphones clean and free of dust using a soft, dry cloth.
- Do not disassemble your headset. All repair works should be carried out exclusively by qualified staff of Energy Sistem Technology, S.A.
- Do not leave the battery completely discharged for a long period of time.

Technical specifications

Audio

- Frequency response: 20 Hz ~ 20 kHz
- Driver diameter: 40 mm
- Neodymium magnet
- Maximum power: 20 mW
- Over-ear design
- Type: dynamic
- Impedance: 32 ohms
- THD: < 1%

Active Noise Cancelling (ANC)

- Up to -25 dB reduction at a frequency between 20 and 1000 Hz.

Connectivity

- Bluetooth® 5.0 (class 2) wireless technology.
- Frequency band: 2.4 GHz
- Maximum output power: < 20.00 dBm
- Compatible Bluetooth® profiles: HFP / A2DP / AVRCP
- Compatible codecs: SBC
- Up to 20 m distance range
- Hands-free function
- Voice assistant compatible with Google / Siri

Hands-free microphone

- Type: built-in microphone
- Sensitivity: -39 dB ± 3 dB
- Frequency response: 100 Hz ~ 10 kHz

Cable

- Length: 120 cm
- Plug: 3.5 mm jack

Battery

- Capacity: 600 mAh / 3.7 V
- Type: lithium-polymer battery
- Battery life with ANC enabled: 16 hours*
- Battery life with ANC disabled: 34 hours*
- Battery life on a 15-minute charge: 1.5 hours (with ANC enabled), 3 hours (with ANC disabled)*.
- Charging time: 3 hours
- Charging method: USB Type-C

*This value is approximate. The battery life depends on the selected volume and the type of music.

Other features

- Adjustable headband
- Protein leather and memory foam ear pads

Product content

- Headphones BT Travel 6 ANC
- USB Type-C cable
- Audio cable
- Hard carrying case
- Quick guide

Buttons and ports



1. VOLUME + / NEXT
2. MULTIFUNCTION BUTTON
3. VOLUME - / BACK
4. STATUS INDICATOR
5. CHARGING PORT
6. MICROPHONE
7. ANC BUTTON
8. AUDIO-IN
9. ANC INDICATOR

Switching on and off the device

To switch on your *Headphones BT Travel 6 ANC*, press and hold the *MULTIFUNCTION BUTTON (2)* for 2 seconds. You will hear a confirmation sound and the *STATUS INDICATOR (4)* will light up white. Press and hold the *MULTIFUNCTION BUTTON (2)* for 2 seconds to switch off your *Headphones BT Travel 6 ANC*. You will hear a sound when yo switch them off.

Bluetooth® pairing

Switch off the *Headphones BT Travel 6 ANC* and press and hold the *MULTIFUNCTION BUTTON (2)* for approximately 4 seconds, until the *STATUS INDICATOR (4)* starts flashing red and white. Your headphones are now ready to be paired with your Bluetooth device. Once *Headphones BT Travel 6* appears on your devide screen, press "connect". You will hear a confirmation sound when both devices are paired.

If you previously paired your *Headphones BT Travel 6 ANC* with a device, they will connect automatically with it next time you turn them on. In case you want to pair them with another device, repeat the pairing process. To do so, press and hold the *MULTIFUNCTION BUTTON (2)* for 4 seconds.

Bluetooth playback control

Once your *Headphones BT Travel 6 ANC* are synchronised, you will be able to control basic playback functions such as turning up and down the volume and switching to the next or previous song directly from your headphones.

Press *VOLUME + (1)* or *VOLUME - (3)* to turn up or down the volume. You will hear a sound when reaching the maximum and minimum volume levels.

Press and hold *NEXT (1)* to skip to the next song. You can also press and hold *BACK (3)* to skip to the previous track.

Press the *MULTIFUNCTION BUTTON (2)* once to pause or resume playback.

Note: *If you're using the audio cable instead of the Bluetooth wireless connection, you will have to control music playback from your music player and not from the headphones.*

Call control

Once your *Headphones BT Travel 6 ANC* and smartphone are synchronised, simply wear your headphones and answer calls with the built-in *MICROPHONE (6)*.

Press the *MULTIFUNCTION BUTTON (2)* to answer an incoming call. If you are listening to music when you receive a call, playback will pause and you will hear an incoming call sound. Press and hold the very same button for 2 seconds to reject a call.

Press the *MULTIFUNCTION BUTTON (2)* to hang up. Playback will resume from where it stopped.

The built-in microphone is designed to answer conventional phone calls from the smartphone. If you intend to connect these headphones to your Windows PC or MAC and use them for home office purposes such as video calls (Teams, Skype, Zoom, etc.), we recommend purchasing this add-on specifically designed for optimal performance: https://www.energysistem.com/headphones-microphone-1-45265-en

Using the Voice Assistant feature

Your *Headphones BT Travel 6 ANC* allow you to directly activate your smartphone's voice assistant via Bluetooth connection. To do so, press the *MULTIFUNCTION BUTTON (2)* twice. You can give the voice command after hearing the confirmation sound.

ANC (Active Noise Cancelling)

To enable or disable the noise cancellation mode, press the *ANC BUTTON (7)* once. The *ANC INDICATOR (9)* glows green while this mode is enabled.

You will experience active noise cancellation, especially at low frequencies, resulting in a decrease of up to 25 dB. This mode is particularly useful in noisy environments such as aeroplanes, trains, buses, etc. It also comes with an optimised sound equalisation.

You can also use ANC mode while not listening to music. Simply wear your *Headphones BT Travel 6 ANC* and press the *ANC BUTTON (7)*.

Important: *For security reasons, we recommend to disable ANC while walking on the street or carrying out activities in which noise reduction may put users at risk.*

Important: *Remember to disable this mode when not using the headphones to avoid running out of battery.*

Audio input

You can also connect your *Headphones BT Travel 6 ANC* to your music player using the provided 3.5 mm mini jack audio cable. You don't need to switch on your headphones if you want to use the audio cable.

To enable this mode, simply plug one cable end into the *AUDIO-IN (8)* and the other end to your music player.

You can use ANC mode while listening to music via audio cable. Bear in mind that this mode consumes battery power and will not be enabled if your headphones? battery is fully discharged.

Note: If you're using the audio cable instead of the Bluetooth wireless connection, you will have to control music playback from your music player and not from the headphones.

Battery life

The battery life of your *Headphones BT Travel 6 ANC* depends on the selected volume and the type of music.
Please take a look at this comparative table to find out more about the approximate battery life of your device:

- Battery life with ANC enabled (while playing music): 16 hours*
- Battery life with ANC disabled (while playing music): 34 hours*
- Battery life on a 15-minute charge: 1.5 hours (with ANC enabled), 3 hours (with ANC disabled).

Important: *These values are approximate. Battery life depends on the selected volume, the type of music and on whether ANC mode is enabled or not.

Important considerations:

- Do not store or leave your device unused or completely discharged for a long period of time.
- Disable ANC mode when not using the headphones to avoid running out of battery.

Charging the battery

When the battery level is below 10%, the *STATUS INDICATOR (4)* flashes red. You will hear a warning sound to remind you to charge it.

The *STATUS INDICATOR (4)* glows red while charging the device and switches off when fully charged. Plug the USB Type-C end of the provided USB cable into your headphones' *CHARGING PORT (5)* and the other USB end into any device with a USB charging port providing energy (PC, USB wall charger, car charger, etc) to charge the battery. The charging time is approximately 3 hours.

Note: The headset will power off and start charging when the charging cable is connected. Current safety regulations mean the headphones cannot be charged and used at the same time.

Caution: Do not charge your headphones with fast charging adapters or dedicated laptop charging adapters, Because their output voltage exceeds 5V and the device may become unusable.

Reset

You can force the *Headphones BT Travel 6 ANC* to shut down by inserting the audio jack connector or charging the device.

Alternatively, you can press and hold the *VOLUME + (1)* button for 5 seconds while the headphones are in Bluetooth® mode (the LED flashes red and white).

Warranty

Find the full warranty terms and conditions at:
https://www.energysistem.com/terms-warranty

Trademarks

All company, brand and product names are trademarks or registered trademarks of their respective companies. Specifications are subject to change without notice.

© 2022 by Energy Sistem Technology, S.A. All rights reserved.

Declaration of conformity

Issuer's name: Energy Sistem Technology, S.A.
Address: C/ Calpe, 1 - 03509 Finestrat, Alicante (Spain)
CIF: A53107488

We declare under our sole and exclusive responsibility that the product:

- Description: wireless headphones
- Brand: Energy Sistem
- Model: Headphones BT Travel 6 ANC
- Manufacturer: Energy Sistem Technology, S.A.
- Manufacturing country: China

referred to in this declaration complies with the essential norms and standards

EN 50663:2017
EN 62479:2010
EN IEC 62368-1:2020+A11:2020
EN 301 489-17 V3.2.4
EN 301 489-1 V2.2.3
EN 300 328 V2.2.2

in conformity with the provisions of the Directive 2014/53/EU of the European Parliament and of the Council of 16th April 2014.

Finestrat, 1st June 2022

Miguel Ángel Aragüez García
Innovation and Technology Director

CE

tehnoteka

https://tehnoteka.rs

Ovaj dokument je originalno proizveden i objavljen od strane proizvođača, brenda Energy Sistem, i preuzet je sa njihove zvanične stranice. S obzirom na ovu činjenicu, Tehnoteka ističe da ne preuzima odgovornost za tačnost, celovitost ili pouzdanost informacija, podataka, mišljenja, saveta ili izjava sadržanih u ovom dokumentu.

Napominjemo da Tehnoteka nema ovlašćenje da izvrši bilo kakve izmene ili dopune na ovom dokumentu, stoga nismo odgovorni za eventualne greške, propuste ili netačnosti koje se mogu naći unutar njega. Tehnoteka ne odgovara za štetu nanesenu korisnicima pri upotrebi netačnih podataka. Ukoliko imate dodatna pitanja o proizvodu, ljubazno vas molimo da kontaktirate direktno proizvođača kako biste dobili sve detaljne informacije.

Za najnovije informacije o ceni, dostupnim akcijama i tehničkim karakteristikama proizvoda koji se pominje u ovom dokumentu, molimo posetite našu stranicu klikom na sledeći link:

https://tehnoteka.rs/p/energy-sistem-slusalice-bt-travel-6-anc-akcija-cena/